

AcuRite weather station

Vložil autotowers1 - 20/02/2026 17:43

Where can I find a diagram explaining how to adjust the barometric pressure on my AcuRite weather station display?

=====

Re: AcuRite weather station

Vložil 1501peg - 20/02/2026 20:10

I spent a whole afternoon once trying to figure out why my AcuRite weather station was showing pressure readings that seemed way off compared to the local airport data, and after some trial and error, I found that the calibration settings were the key. You can usually access the calibration mode by holding down certain buttons, but the exact procedure varies by model, and the official instructions can be a bit confusing. I ended up bookmarking a site that has the clearest breakdown of the process I've found, and it's saved me a few times since then: <https://acurite.manymanuals.com/> acurite weather station manual. It walks you through the steps for setting the relative pressure offset, which is crucial for getting accurate forecasts based on your specific elevation. Once I adjusted it to match my local weather service reading, the station has been spot-on ever since.

=====

Re: AcuRite weather station

Vložil autotowers1 - 20/02/2026 20:57

Thank you so much for the detailed instructions! I was just about to dive into the settings on my AcuRite, and this guide is perfect. You saved me a ton of time, I'm off to try the calibration now.

=====